



J/24 Quick Tuning Chart

Old Loos Gauge PRO Model B

J
24

WIND SPEED (TWS)	UPPERS (Loos gauge B)	UPPERS (turns from base)
0-5	18	-1

LOWER (Loos gauge B)	LOWER (turns from base)
10	-1

UPPERS Turnbuckle/Caliper number

LOWER Turnbuckle/Caliper number

WIND SPEED	UPPERS	UPPERS	Port=	Stb=
5-8 BASE	20	BASE		
8-10	23	1		
10-12	24	0.5		
12-14	27	1.5		
14-16	29	1.5		
16+	29	0		

LOWER	LOWER	Port=	Stb=
15	BASE		
18	0.5		
21	0.5		
24	0.5		
27	1		
31	1.5		

Your Uppers Settings

Your Lower Settings

Notes: Turns above are for the open body turnbuckles, for Ronstand turnbuckles double these turns.