



GO BEYOND™

J/24 Quick Tuning Chart

New Loos Gauge PRO Model PT-2

J 24

WIND SPEED (TWS)	UPPERS (Loos gauge B)	UPPERS (turns from base)
0-5	13	-1

LOWER (Loos gauge B)	LOWER (turns from base)
9	-1

UPPERS Turnbuckle/Caliper number

LOWER Turnbuckle/Caliper number

WIND SPEED	UPPERS	UPPERS	Port=	Stb=
5-8 BASE	15	BASE		
8-10	17	1		
10-12	18	0.5		
12-14	22	1.5		
14-16	24	1.5		
16+	26	0		

LOWER	LOWER	Port=	Stb=
12	BASE		
13	0.5		
15	0.5		
18	0.5		
22	1		
26	1.5		

Your Uppers Settings

Your Lower Settings

Notes: Turns above are for the open body turnbuckles, for Ronstand turnbuckles double these turns.